

3

6


O

5

Yale® Assure Lock® SL Key Free Touchscreen Deadbolt Installation and Programming Instructions



Preparing Door





FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN DAMAGE TO THE PRODUCT AND VOID THE FACTORY WARRANTY


An ASSA ABLOY Group Brand


P/N YRD256-121 Issue1 1118

ASSA ABLOY











2 Installing


Installing Touchscreen Escutcheon









Installing Interior Mounting Plate












5 Installing Interior Escutcheon








Testing Operation






6 Installing Batteries/Handing the Lock




Lock automatically adjusts for proper handing.

Installing Optional Network Module




8 Installing Cover



Congratulations, you've installed the Yale® Assure Lock® SL Key Free Touchscreen Deadbolt Turn sheet over to Programming Instructions to customise your product.

Programming Instructions

Exterior Escutcheon



Lock Activation







Master PIN Code must be created before any further programming Max User Codes = 250 with Network Module. Max User Codes = 25 without.

Definitions

All Code Lockout Mode: This feature is enabled by the Master code. When enabled, it restricts all user (except Master) PIN code access. When attempting to enter the code while the unit is in Lockout, the RED locked padlock will appear on the screen.

Automatic Re-lock Time: After a successful code entry and the unit unlocks, it will automatically re-lock after thirty (30) seconds

Inside Indicator Light: Located on the interior escutcheon. Shows active status (Locked) of lock and can be enabled or disabled in the Advanced Lock Settings (Main Menu selection #3).

Language Setting Mode: Choosing English (1), Spanish (2), or French (3) becomes the (default) setting for the lock's voice prompts.

Low Battery: When battery power is low, the Low Battery Warning indicator flashes RED. If battery power is completely lost, use the 9V battery override. To use the 9V battery override apply 9V battery, in either direction, to terminals below the touchscreen for backup power option. Wake up the lock and enter your PIN code to unlock the door.

Master PIN Code: The Master PIN code is used for programming and for feature settings. It must be created prior to programming the lock. The Master code will also operate

Network Module Setting: With the optional Network Module installed, this setting becomes available thru the Main Menu (7) and allows the lock to connect with a network controller.

One Touch Locking: When the latch is retracted, activating the keypad will extend the latch (During Automatic Re-lock duration or when Automatic Re-lock is disabled). When the One-Touch Re-lock is **not** in use **(disabled)**, any valid PIN code will re-lock the lock.

Previous: While in Menu Mode, pressing this icon cancels the current operation and returns the user to the previous step

Privacy Mode: Privacy Mode is disabled by default. Enable Privacy mode by pressing the privacy button for 4 seconds to put the lock in do-not-disturb mode (all PIN codes are

Shutdown Time: The unit will shutdown (flashing RED) for sixty (60) seconds and not allow operation after the wrong code entry limit (5 attempts) has been met.

Tamper Alert: Audible alarm sounds if attempting to forcibly remove outside escutcheon


User PIN Code: The User code operates the lock. Maximum number of user codes is 250 with Network Module: without Network Module, maximum is 25 user codes. Note: When deleting User PIN code(s), screen will display User Number (not PIN code) being deleted.

Volume Setting Mode: The volume setting for PIN code verification is set to **Low (2)** by default: otherwise it can be set to **High (1)** or **Silent (3)** for quiet areas.

Wrong Code Entry Limit: After five (5) unsuccessful attempts at entering a valid PIN code, the unit will shut down and not allow operation.





Creating a Master PIN Code must be performed upon installation or after resetting the lock to factory default. Programming and use of lock is not possible until this step has been successfully completed.




Creating User PIN Codes Master PIN Code must be created first.

*Max user codes = 250 with Network Module,Max user codes = 25 without,





Unlocking Door with PIN Code



Code Chart Duplicate if necessary


PIN Cod	de Management (with Network Mo	dule - Up to	250 Users)
User Type	User Name	User #	PIN Code
Master			
User			

Resetting Lock to Factory Default

When lock is reset to factory defaults all user codes (including the Master PIN code*) are deleted and all programming features are reset to original default settings (see below).

- 1. Remove the battery cover and batteries.
- 2. Remove the interior escutcheon to access the reset button. 3. The reset button (see image at right) is
- located beside the PCB cable connector. 4. While pressing the reset button (minimum of 3 seconds) reinstall batteries. Release reset
- 5. Replace battery cover.

Upon reset, Master PIN Code creation is the only option available and must be performed prior to any other programming of the lock.




Settings	Factory Setting	
Master PIN Code	Registration <i>required*</i>	
Automatic Re-lock	Disabled	
Inside Indicator Light	Disabled (Off)	
One Touch Locking	Enabled	
Privacy Button Setting	Disabled	
Volume Setting	Enabled (Low)	
Language Setting	English	
Lockout Mode	Disabled	
Automatic Re-lock TIme	30 seconds	
Wrong Entry Code Limit	5 Times	
Shutdown Time	60 seconds	
	·	

*The Master PIN Code must be registered prior to any other programming of the lock.

Feature Programming Through Menu Mode Using Master PIN Code*

- 1. Touch screen with back of hand or palm to activate.
- 2. Enter 4-8 digit master PIN code* followed by key.
- Lock Response: "Menu mode, enter number, press key to continue." 3. Enter digit corresponding to the function to be performed followed by the key. Follow the voice commands
- *The Master PIN Code must be registered prior to any other programming



3 French

3 Disable 🗘

8 ***Programming with Module Device T1 Setup Digital Keys - O

3 Exit the Network 🗘

3 Transfer Data •

6 Lockout Mode T 1 Enable 🗘

**This function appears only with

***This function appears only with

Bluetooth version installed.

Programming Troubleshooting

Symptom	Suggested Action
Lock does not respond - door is open and accessible.	 Touchscreen becomes active when pressed w/ whole hand. Use a larger area of the hand or fingers and verify contact with at least 3 areas. If touchscreen numbers are visible, check to see if they respond when pressed. Check batteries are installed & orientated correctly (polarity) in the battery case. Check batteries are in good condition; replace batteries* if discharged. Check to see if touchscreen harness is fully connected and not pinched.
Lock does not respond - door is locked and inaccessible.	Batteries may be completely discharged. Apply 9V battery to terminals below the touchscreen for backup power option.
Unit is on for awhile then shows no reaction. Lights dim.	Batteries do not have enough power. Replace batteries.
Unit chimes to indicate code acceptance, but the door will not open.	Check the door gaps for any foreign objects between door and frame. Check the wiring harness is firmly connected to the PCB.
Unit operates to allow access, but will not automatically re-lock.	 Check to see if Auto - Re-lock Mode is enabled. Disable Auto-Re-lock Mode to lock the door (automatically). If low battery indicator is lit (see below) change batteries.*
PIN codes will not register.	 PIN codes must consist of 4 to 8 digits to register. The same PIN code cannot be used for multiple users. Registration/management of PIN codes is set by the authority of Master Code, which is set first. Contact the Master user. User codes must be entered within 5 seconds (while touchscreen is active) or process will have to be restarted. Check ✓ or gear cannot be used as part of the PIN code.
Upon entering a PIN code and pressing the key, the unit displays "invalid code" error or lock times out without responding.	Lockout Mode is enabled. Only the Master can enable/disable Lockout Mode. Contact the Master user.
Upon entering a PIN code and pressing the () key, the red padlock icon appears and there are different tones.	Check to see if the lock is set to Lockout Mode. Setting/managing Lockout Mode is done through Master Code only. Contact the Master user.
The unit operates, but it makes no sound.	• Check to see if Silent Mode is enabled (see Feature #4).
The unit responds "Low Battery"	This is the alert to change the batteries. Replace all four (4) batteries* with new AA Alkaline batteries.
Upon entering a PIN code and pressing the√key, the unit responds "Wrong number of digits".	The digits entered were incorrect or incomplete. Re-enter the correct code followed by the check key.

*When batteries are replaced, Network Module locks have a real time clock that will be set through the User Interface (UI): it is recommended to verify correct date and time particularly those locks operating under Daylight Saving Time (DST).

Hardware Troubleshooting

Cycle lock in both the locked and unlocked positions. If problems are found:


a. Check that door and frame are properly aligned and door is free swinging. b. Check hinges: They should not be loose or have excessive wear on knuckles.

Bolt will not deadlock

- a. Check for sufficient clearance of the bolt within the strike-side jamb. Correct this by increasing the depth of the pocket for the bolt.
- b. Check for misalignment of bolt and/or strike which may be preventing bolt from properly entering the strike. With the door open, extend and retract the bolt; if it is smooth, check the strike aligment.

Bolt does not extend or retract

- a. Bolt and strike are misaligned, see above.
- b. Check the backset of door relative to adjustments already made to bolt.
- c. Verify proper door preparation and re-bore holes that are too small or misaligned.
- d. Verify keypad wire harness is routed under the bolt (see Fig. A)
- e. Verify bolt is installed with correct side up (Fig. A).



Keypad numerics are scrolling

Remove interior escutcheon and check to ensure that the wire harness lies flat against the back recessed area and is properly routed along the side of the escutcheon and tucked under the plastic cable guide.

NOTE TO INSTALLER AND CONSUMER

While Yale® has included several features to prevent lockout (9-Volt battery jumper, low battery warnings), it is still possible for a lockout situation to occur. Because this product does not have a mechanical override (a key). Yale® recommends to use this product in an environment where there are additional entry points into the dwelling.

Class B Equipment

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment meets the Regulatory Compliance Mark (RCM) requirements for Australia and New Zealand. This equipment has been tested in accordance with the requirements EN 61000-6-3 and EN 55032, Class B limits.

Warning: Changes or modifications to this device, not expressly approved by Yale Security **Inc.** could void the user's authority to operate the equipment

Yale Locks & Hardware

Australia Product Support Tel 1300 LOCK UP • www.yalelocks.com.au

Yale Locks & Hardware is a division of Yale Security Inc., an ASSA ABLOY Group Company.

New Zealand Product Support nzsales@assaabloy.com • www.yalelocks.co.nz

Yale® and Yale Secure Connect are registered® trademarks of Yale Security Inc., an ASSA ABLOY Group Company. Assure™ Lock is a trademark of Yale Security Inc., an ASSA ABLOY Group Company. Other products' brand names may be trademarks or registered trademarks of their respective owners and are mentioned for reference purposes only. © Copyright 2018. Yale Security Inc., an ASSA ABLOY Group Company, All rights reserved. Reproduction in whole or in part without the express written permission of Yale Security Inc. is prohibited.

YALE, with its unique global reach and range of products, is the world's favourite lock - the preferred solution for securing your home, family and personal belongings.

ASSA ABLOY is the global leader in door opening solutions, dedicated to satisfying end-user needs for security, safety and convenience.

ASSA ABLOY Australia Pty Limited, 235 Huntingdale Rd, Oakleigh, VIC 3166 ABN 90 086 451 907 &2018 The global leader in door opening solutions

ASSA ABLOY

**Network Module locks only