ASSA ABLOY is the global leader in door opening solutions, dedicated to satisfying end-user needs for security, safety and convenience



## Please Note:


This document is provided as a dimensional reference and should not be printed as a drilling template unless it can be correctly scaled to 100% by your printer.




## DOOR PREPARATION PROCEDURE




For use with **Nexion Mechanical Lockset and** Nexion Keyless Entry Lockset







• Drill Ø25mm hole from both sides of the door to prevent splintering in the position shown.




 Drill the Ø25mm latch hole horizontally to a minimum depth of 90mm for 60mm backset.




- Slide latch into hole and mark around latch face plate.
- Chisel out face plate recess to a depth of 3.5 mm.
  Mark and drill 2 x Ø2.5mm holes for the latch screws.
- Insert latch with angled face of bolt towards door jamb and fasten with 2 x 20mm screws provided.




- · Insert SPINDLE into latch as shown.
- Position DRILL TEMPLATE over SPINDLE and align notches with the marked backset position.



- · Make sure the Drill Template is vertical.
- Drill 4 x Ø 2.5 mm pilot holes through template. · Repeat the same process on the other side of
- the door.



 Drill 3 x Ø10mm holes and 1 x Ø54mm hole from both sides of the door in the positions shown to prevent splintering.



• When completed make sure holes are free of any sawdust or loose material.

ASSA ABLOY Australia Pty Limited, 235 Huntingdale Rd, Oakleigh, VIC 3166 ABN 90 086 451 907 ©2009

The Global Leader in Door Opening solutions

**ASSA ABLOY**