

Fixing 120 Series Toilet Partition Hardware Leg to the Floor Installation Instructions

120_200SS, 120ALUM-Series, DESIGNER_120ALUM

- 1) Using an Allen Key, release the grub screw from the leg (Image 1).
- 2) By completing step 1, this will release the floor grommet (Image 2).



- 3) Fix grommet to the floor using screw provided.
- 4) Return leg assembly to the base (floor grommet).
- 5) Lock in Grub Screw using Allen Key for secure fixing.