

Nexion Mechanical Entrance Lockset



www.lockweb.com.au

LOCKWOOD

ASSA ABLOY

Nexion Mechanical Entrance Lockset

Mechanical Operation

To Enter (unlock)

- From the outside, rotate key 90° clockwise
- Open the door
- Turn key anticlockwise to remove key
- When key is removed the lock automatically locks to yellow (This is a safety feature). To disengage pull down on the inside handle (green), the door will stay unlocked until manually snibed or key locked.

To Lock (when exiting with nobody inside)

- From the inside, open the door
- With door ajar, turn snib to yellow
- From the inside rotate the key (360° clockwise) to red
- Remove key
- Pull door shut behind you after exiting



Snib position **PassageMode**
green indication



Snib position **SafetyMode**
yellow indication



Snib position **SecureMode**
red indication



LockAlert™
Interior Indicator shows lock status at a glance.



Secure Mode
Securely locked from both inside and outside. For when nobody is home.



Safety Mode
Securely locked from outside and free from inside.



Passage Mode
Free to enter from outside and free to exit from inside.

We take the worry out of protecting what's valuable to you.
Lockwood: no worries®

