
FDBU60

Fitting Instructions: Fire Door Bottom Upgrade



Architectural Door Seals



Length:

Description of contents

- Aluminium carrier (1)
- Pre-slotted holes (2)
- Flexible gasket (3)
- Kilargo Intumescent fire seals DO NOT REMOVE. (4)
- Bag of screws
- Fitting instructions

Tools required for installation

- Tape measure
- Saw (power or hand)
- Screw driver
- 2.5mm drill bit
- Drill (power or hand)
- Knife
- Pencil or marker

Other Integrity™ Architectural Seals include:

- Door Perimeter Seals
- Door Bottom Seals
- Automatic Door Bottom Seals
- Threshold Plates
- Brush Seals
- Magnetic Seals

Contact your nearest Kilargo office for further details.

Literature Code: FDBU60 05/12

Installation detail: Fire door bottom upgrade

This seal contains Intumescent material and is used for upgrading AS1905/1 fire door assemblies with non compliant / excessive door bottom clearances. It is approved for use on gaps up to 60mm It is not necessary to remove the door from the hinges and no painting is required after installation.

Step 1	Remove the FDBU60 seal from the packaging.
Step 2	With the door closed, measure the width of the door.
Step 3	Remove the flexible gaskets from the aluminium carrier.
Step 4	Cut the aluminium carrier and integral intumescent strips to length required (door width)
Step 5	Cut the flexible gaskets to suit the aluminium carrier.
Step 6	Refit the flexible gaskets to the aluminium carrier.
Step 7	Apply the seal to the door bottom and mark out the slotted hole locations with a pencil ensuring the flexible gasket blades lightly touch the floor.
Step 8	Drill pilot holes with a 2.5mm drill bit.
Step 9	Fix the FDBU60 seal to the bottom of the door leaf through the slotted holes with the screws provided. (For uneven gaps, slight adjustment can be made via the slotted holes prior to tightening the fixing screws.
Step 10	Ensure that the door freely closes and latches

Note

Recommendations as to methods for use of materials and construction details are based on the experience and knowledge of Kilargo and are given in good faith as a general guide and service to designers, contractors and manufacturers.

Kilargo reserves the right to make alterations or delete any installation detail without prior notice.

Important

Australian fire door designs are proprietary by nature and therefore it is a requirement that door seals and other items of essential hardware are tested in accordance with AS1530/4 with each fire door manufacturers' door type to ensure that they do not compromise the assembly's established fire resistance.

Ensure that the installation of this product does not impede the opening or closing of the door. It is recommended to check the adjustment of the door seal periodically to ensure the door assembly to which it is fitted, closes and latches properly.



